

supplementary

Kawasaki ZX6R 2003-04



1) Ignition coils



Disconnect connectors from ignition coils and insert connectors of QS. Order is arbitrary. Check if RED wire of motorcycle wiring harness is connect with RED wire of QS wiring harness.

2) Ground connection

Connect black wire of QS to negative terminal of battery (or to frame of motorcycle)

4) QS sensor

Connect QS sensor to QS wiring harness - black 2 pin connector.



Ignition coils